

Pratleymix Instructions

1. Remove dirt, grease, rust and paint from the application surfaces by wire brushing, scraping and sand papering. Oil or grease should be removed by any non-oily solvent. The rougher the cleaned surfaces, the better.
2. In cold weather, slight warming of the tins will make mixing and application easier.
3. The two components must be mixed in equal proportions. Do not mix more than can be used in 15 to 20 minutes.
4. Use separate spatulas for each tin. Do not mix the lids of the tins. Reseal tins properly after use.
5. This product will set hard in 3 to 5 hours depending on ambient temperature, and cure to maximum strength in 24 hours. Hardening and curing can be accelerated by heating to not more than 150 degrees Celsius. Warming is recommended in cold weather to avoid an unduly long curing period.

Mixing

1. Measure equal proportions from each tin, using separate spatulas. Replace lids on the correct tins, according to colour.
2. Mix thoroughly until colour is quite uniform.

Application

Using a suitable tool (putty knife, trowel, etc) spread and work onto surface. Remove excess and clean surrounding surfaces with a damp cloth. Smooth by stroking lightly with tool or wet finger when partially set.

Caution

Although this product contains the mildest ingredients, hands should be washed after use. A barrier cream should be applied to hypersensitive skins or when using frequently.