

## **Kraftex Antique Cracks Base Coat for small cracks (Part 1 of a 2 part water based system)**

Congratulations on the purchase of your Kraftex Antique Cracks Base Coat – another quality home craft product made by Pratley, and intended for use in conjunction with Kraftex Antique Cracks Top Coat.

Kraftex Antique Cracks will enable you to effortlessly and quickly create a unique antique effect on a variety of painted craft, hobby and artistic objects, even large surfaces like doors and walls!

### **Instructions:**

1. Make sure that you have purchased the Base Coat that suits your needs – Base Coat for small cracks or Base Coat for Large Cracks.
2. Shake the container thoroughly.
3. Apply one coat of Kraftex Antique Cracks Base Coat (Small or Large cracks)
4. Allow to dry until it looks clear. A minimum time of 15 minutes and a maximum of 6 hours. (Do not leave overnight)
5. Apply Kraftex Antique Cracks Top Coat over this base coat, following the instructions given.

<b>Tip</b>	<b>Why</b>
1. To get smaller cracks, apply in hotter weather. To get larger cracks, apply in colder weather.	1. The cracking is temperature sensitive.
2. Have patience with the drying time of Antique Cracks during cold weather conditions.	2. Antique Cracks will take longer to dry and crack in colder weather.
3. Apply Kraftex Antique Cracks Top Coat over the base coat as soon as the base coat looks clear.	3. If the base coat dries for too long (overnight) the top coat can get embrittled. (flakes off)